



# Wrap Strap

## House Wrap Strapping



WrapStrap is a Polythene embossed strap that is installed around the building wrap to keep the insulation in place and prevent it from bulging into the cavity for buildings with a drained cavity application. WrapStrap can also be used as a support for non-self supporting roof underlay.

Masons WrapStrap	Masons Code
Blue pp strap 19mmx300m	WRAPST19X300
Blue pp strap 25mmx250m	WRAPST25X250

### New Zealand Building Code Standard (NZBC)

The NZBC requires Building-wrap to be restrained from bulging into a drained cavity where stud spacings are greater than 450 mm. This to prevent the building wrap and insulation from protruding into the drained cavity. Acceptable means of achieving this are by using strapping at 300mm centres fixed horizontally and drawn taut.